

## REVERSE MASKS

### MAINTENANCE INSTRUCTIONS

#### GENERAL INFORMATION:

Two masks of faces are mounted side by side--the right one is concave, while the left one is convex. As you walk back and forth in front of the masks though, the right one seems to follow you. This exhibit consists of a wall-hung box containing two masks and two small fluorescent lamps.

#### Cleaning the Exhibit:

The outside of the exhibit, and the walls of the inside are formica and may be cleaned with a mild soap solution or general purpose cleaner. The masks are fiberglass with a colored gel coat and may also be cleaned with a mild soap solution or general purpose cleaner using a soft wipe that will not leave scratches, (we suggest Wype-All™).

#### 115 Vac to 230 Vac conversion:

A line voltage switch labeled 230 (or 115 depending upon the position) is located in the back of the exhibit. Check this switch during initial set-up, before it is hung on the wall and before plugging it in. The circuit breaker will protect most accidental improper connections, however some circuits may sustain damage if connected to 230 Vac if the line voltage switch is left at 115 Vac.